

Disposable Heel Grounder

The disposable heel grounder is designed for plant visitors and other temporary workers who enter static controlled areas. It is made from antistatic fabric and provides safe and effective resistance.

The disposable heel grounder uses the conductive yarn in the antistatic fabric to create and maintain electrical contact between the ground and body and can optimize static dissipation.

Features

- Easy to use / comfortable to wear
- Economic cost
- Non-marking
- Surface Resistivity 10^5 Ohms

Notes

This product comes in packs of 10 sheets. Each sheet contains 10 individual heel grounders.

A dispenser is available for this product, reference code 068-0009.



Colour	Composition	Sizes (in)	Package
Yellow	100% Polyester & Conductive coating	Length: 11in	10pcs/sheet
		Length: 5.9in	100pcs/bag

Product Code	Description	Additional notes
068-0009	Disposable Heel Grounder	Pack of 100
068-0019	Dispenser for 068-0009	Each

Important Notice: This data sheet and its contents (the "Information") belong to Antistat or are licensed to it. No licence is granted for the use of it other than for information purposes in connection with the products to which it relates. No licence of any intellectual property rights is granted. The Information is subject to change without notice and replaces all data sheets previously supplied. The Information supplied is believed to be accurate but Antistat assumes no responsibility for its accuracy or completeness, any error in or omission from it or for any use made of it. Users of this data sheet should check for themselves the Information and the suitability of the products for their purpose and not make any assumptions based on information included or omitted. Liability for loss or damage resulting from any reliance on the Information or use of it (including liability resulting from negligence or where Antistat was aware of the possibility of such loss or damage arising) is excluded. © Antistat 2020.

Disposable Heel Grounder



1 Remove strip to reveal adhesive layer on the underside of the disposable heel grounder.



2 Place the adhesive layer firmly on the sole of the shoe covering at least half of the heel with the rest of the strip behind the shoe.



3 Insert the other end of the heel grounder in the shoe or sock to create the skin-to-ground contact.



4 It is important for the effectiveness of this product that the heel grounder stays under foot when the shoe is on. Repeat this process for the other shoe.



Buy online at
www.antistat.com



Call us on
+1 512-580-4220



Email us at
sales@antistat.com



Message us on Live Chat
www.antistat.com

Important Notice: This data sheet and its contents (the "Information") belong to Antistat or are licensed to it. No licence is granted for the use of it other than for information purposes in connection with the products to which it relates. No licence of any intellectual property rights is granted. The Information is subject to change without notice and replaces all data sheets previously supplied. The Information supplied is believed to be accurate but Antistat assumes no responsibility for its accuracy or completeness, any error in or omission from it or for any use made of it. Users of this data sheet should check for themselves the Information and the suitability of the products for their purpose and not make any assumptions based on information included or omitted. Liability for loss or damage resulting from any reliance on the Information or use of it (including liability resulting from negligence or where Antistat was aware of the possibility of such loss or damage arising) is excluded. © Antistat 2020.